



Initialisierung für Barcode-Scanner UPC-Code (mit führender Null)

<i>Metrologic Voyager 1200g</i>	
	 DFMBK30099630012F43001F100. Convert UPC-A to EAN-13
<i>Metrologic Voyager 9520</i>	
	 3 1 0 7 5 1 4 Convert UPC-A to EAN-13
<i>Metrologic MS 950-Serie</i>	
	Enter/Exit Program Mode  Convert UPC-A to EAN-13  L Z 3 Enter/Exit Program Mode  * *